



W601 RTU

Contents

1- W601 Controller	3
2- Features (general)	4
3- Enclosure specification and installation	5
3-1 Enclosure Internal structure	5
4- Menu and function	7
4-1 RS-232C port	7
4-2 Control	8
4-3 Voltage signal	8
4-4 Current signal.....	8
4-5 Main	9
4-5-1 Online	9
4-5-2 Status	10
4-5-3 EVENT	10
4-5-4 Measurement	13
4-5-5 FTU MANAGEMENT	14
4-5-6 Device Management	19
4-5-7 Calibration.....	20
4-5-8 Battery Status	21
4-5-9 Fault Ind. Reset	22
4-5-10 Lamp Test	22
5- DNP 3.0 profile for remote communication	24
6- DNP3 stages:	26
6-1 Binary input point	26
6-2 Binary output point	26
6-3 Counters.....	27
6-4 Analog input	28
7- Earthing	29
8- Control cable and power cable	29

1- W601 Controller

Over view

The W601 controller is installed in the control panel switch and is capable of reporting the information to the control center and receiving the commands.

In order to process information such as measurement and fault detection in a fast and accurate way, a 16-bit DSP and a 3-phase parameter measurement specific processor is used to perform the communication with HMI and information transfer.

- Analog data processing, control and monitoring
- Measurement of current, voltage, power (active, reactive, apparent), power factor
- DNP-3.0 communication protocol in distribution network
- LAN port
- USB port
- RS-232c port
- Calibration
- Variable power supply for modem
- Battery test

2- Features (general)

Parameter	Value
Input voltage	220VAC
Battery voltage	24VDC
Power consumption	≈ 15W
Operation temperature	-25°C to 70°C
Humidity	5 – 95 %RH
Panel Size	400×600×206 mm
Panel stand size	800×80×20 mm
Weight	45 KG

Description	Qty.
Analog input (current measurement)	4
Analog input (voltage measurement)	6
Digital output	1
LAN port	1
Serial port	1
USB port for data offload and firmware upgrade	1

3- Enclosure specification and installation

The enclosure is designed and manufactured in order to protect the function of RTU in improper environments.


Enclosure view:

The enclosure body is designed so that it could work normally under low or high temperature and humid environment.


The enclosure could ventilate the inside warm environment through the air vents on the back of it.

Both control and power cables should be connected to the sockets under the enclosure correctly, because improper connection would lead to errors in the control systems function.


While the device is going to be stored in the warehouse or not been used for a long time, switch off the key on the panel.



3-1 Enclosure Internal structure



A	Display and keyboard
B	Door lock
C	Door latch
D	Main door lock
E	Door sensor
F	Main power key
G	Door holder
H	Document place



LED Signal	Status	Description
PWR	OFF	AC disconnected
	ON	AC connected
	Blink	AC disconnected and battery discharged - device would be powered off after about 1 min.
RUN		System is normal
FAULT		Error indicator
SYNC FAIL		Phases not synchronized
HOTLINE (SOURCE)		Voltage indicator (source)
HOTLINE (LOAD)		Voltage indicator (load)
HANDLE LOCK		LBS lock is enabled
GAS LOW		Gas pressure low

4- Menu and function

4-1 RS-232C port

Pin	Signal	Description
1	DCD	
2	Rx	
3	Tx	
4	DTR	
5	GND	
6	DSR	
7	RTS	
8	CTS	
9		

4-2 Control

Signal	Description	Remark
Open	LBS Open Cantect	
Close	LBS Close Cantect	
Bat Test	Bat Test Output	
Lock	Control Lock Cantect	
Unlock	Control Unlock Cantect	

4-3 Voltage signal

Signal	Description	Remark
-	-	-
-	-	-
Phase A	PT A Input	
Phase B	PT B Input	
Phase C	PT C Input	
Ground	PT Ground Input	
Phase A	PT A Input	
Phase B	PT B Input	
Phase C	PT C Input	
Ground	PT Ground Input	

4-4 Current signal

Signal	Description	Remark
Phase A	CT A Input	
Phase B	CT B Input	
Phase C	CT C Input	
Common	CT Common	

4-5 Main

MAIN
Online
Status
Event
Measurement
FTU Management
Device Management
Calibration
Battery Status
Fault Ind. Reset
Lamp Test

4-5-1 Online

Voltage	
VA: 0.0	VR: 0.0
VB: 0.0	VS: 0.0
VC: 0.0	VT: 0.0
Current	
IA: 0.0	
IB: 0.0	
IC: 0.0	
IN: 0.0	

This menu contains 2 sections. In the first section the voltages of both sides of the LBS are displayed, the second section contains the currents, including the neutral current.

4-5-2 Status

STATUS	
Control	
LBS:	Undefined
Handle Lock:	Free
Gas Pressure:	Normal
Protect:	Unlock
Control:	Remote
Door:	Open
Power	
External Power:	Off
Battery:	Normal
Charger:	Fail
Communication	
Master Address:	20
DNP Address:	2416
Temperature:	20
System info	
Serial Num.:	W601950018
Version:	30

Control: Displays the LBS and control panel status

Power: Displays the external power supply and battery status

Communication: Displays the communication status

System Info: Displays the control panels serial and firmware version

4-5-3 EVENT

In this menu, all events are shown including time of occurrence and description.

EVENT	
Counter	
Switching Event	
Fault Current	
Avg Load Current	
Peak Load Current	

4-5-3-1 Counter:

The numbers of resets, number of LBS switches, permanent and temporary current errors are displayed in this menu.

Counter	
Restart:	51
Switch:	12
Permanent F.I. :	0
Temporary F.I. :	4

4-5-3-2 Switching Event

The local/remote closing time and date of the switch is displayed in this menu.

Switching Event			
1	2016:10:26	15:19:33	
	Close	Local	
2	2016:10:25	15:28:54	
	Close	Local	
3	2016:10:25	13:16:18	
	Close	Local	
4	2016:10:24	16:03:52	
	Close	Local	
5	2016:10:24	10:16:08	
	Close	Local	

4-5-3-3 Fault current:

The time and date of current fault is displayed in this menu.

Fault Current				
1	2016:08:14	12:16:25	0	
	266	792	262	258
2	2016:08:14	12:16:25	0	
	262	258	266	0
3	2016:08:14	12:16:25	0	
	0	0	262	258
4	2016:08:14	12:16:25	0	
	262	0	0	0

4-5-3-4 AVG Load Current:

Avg Load Current				
1	2016:08:14	12:15:00	170	
	262	778	258	254
2	2016:08:14	12:15:00	170	
	268	254	262	656
3	2016:08:14	12:15:00	170	
	223	656	258	254
4	2016:08:14	12:15:00	170	
	258	216	223	656

4-5-3-5 Peak Load Current

Peak Load Current				
1	2016:08:30	12:15:00	170	
	41	43	42	41
2	2016:08:30	12:15:00	170	
	42	41	41	23
3	2016:08:30	12:15:00	170	
	22	23	42	41
4	2016:08:30	12:15:00	170	
	42	22	22	23

4-5-4 Measurement

Active power, reactive power, apparent power, PF, voltage THD and current THD are displayed in this menu.

Measurement	
Active Power	
Reactive Power	
Apparent Power	
Power Factor	
THD V Source	
THD V Load	
THD Current	
A(KW):	0.0
B(KW):	0.0
C(KW):	0.0

4-5-5 FTU MANAGEMENT

4-5-5-1 Setting

4-5-5-1-1 Fault Report menu

Description	Classification	Default	Ranges	Step
Fault I report	Event Set	No	Yes/No	
	Static Reset	No	Yes/No	

4-5-5-1-2 Delay Time menu

Description	Classification	Default	Ranges	Step
Delay Time	On/Off Level*	4s	0.1s~60s	0.1s
	Phase Diff.	4s	0.1s~60s	0.1s
* Delay time for displaying the On/Off level change				

4-5-5-1-3 Sync. Lock menu

Description	Classification	Default
Sync. Lock	Enable Disable	Enable
Check and change the phase sync. While pressing Open and Close		

4-5-5-1-4 Do On-Time menu

Description	Classification	Default	Ranges	Step
-------------	----------------	---------	--------	------

Do On-Time	On-Time	20	10~3000	1ms
Time of motor voltage on				

4-5-5-1-5 Feeding Methods menu

Description	Classification	Default	Ranges	Step
FEEDING METHOD	Phase Reversal	Normal	Normal/Reverse	
	Feeding Factory	Disable	Disable/Enable	
If the Feeding factory is enabled, voltage could be applied from small power plants				

4-5-5-1-6 Phase Pick-Up menu

Description	Classification	Default	Ranges	Step
Pick-Up Current	Phase	200A	120~840A	5A
	Ground	30A	10~420A	5A
Minimum required current to report current error				

4-5-5-1-7 Inrush Time menu

Description	Classification	Default	Ranges	Step
Inrush Time	Phase	1.5s	0.1s~3.0s	0.1s
	Ground	1.5s	0.1s~3.0s	0.1s
The error duration time should be more than Inrush time to be able to report current error				

4-5-5-1-8 On/Off Level menu

Description	Classification	Default	Ranges	Step
Voltage On/Off Level	On Level	80	70~85	5%
	Off Level	50	50~75	5%
The hysteresis amplitude of voltage on/off				

4-5-5-1-9 Phase Difference menu

Description	Classification	Default	Ranges	Step
PHASE DIFF.	Phase Diff.	50D	0~80D	10D
Angle value required for sync. report				

4-5-5-1-10 F.I.Setting Time menu

Description	Classification	Default	Ranges	Step
F.I.Setting Time	Permanent	20	1~180	1s
	Temporary	2	1~180	1s
Suitable time range for reporting current errors				

4-5-5-1-11 V.O.C Set menu

Description	Classification	Default	Ranges	Step
V.O.C	V.O.C	5%	0~50%	1s
	Minimum VOC	100A	0~6030a	1A
Variations which would make an Event (Minimum VOC is the offset and amplitude variations of VOC)				

Communication config menu is used for setting the communication items. These settings include DNP communication protocol and modem setting.

4-5-5-2 Config

Setting Items	Sub Setting Items	Setting Ranges<Step>
Comm. Speed	Speed	2400/4800/9600/19200bps
D/L Confirm	Confirm	Yes/No/Sometime
D/L Setting	Retries	0~2<1>
	Timeout	0s~100s<1s>
A/L Confirm	Confirm	Enable/Disable
A/L Setting	Retries	0-2<1>
	Timeout	0s~100s<1s>
Unsolicited Mode	Unsol. MSG	Enable/Disable
	Unsol. Time	10ms~5000ms<10ms>
Unsolicited Class	Class 0	Enable/Disable
	Class 1	Enable/Disable
	Class 2	Enable/Disable
	Class 3	Enable/Disable
Master Address	Address	0~65534<1>
DNP Address	Address	0~65534<1>
SBO Time	Time	1s~255s<1>
Debounce Time	Debounce	10ms~100ms<5ms>
Multiframe Interval	Interval	100ms~5000ms <10ms >

4-5-5-2-1 Modem and Communication menu

Description	Classification	Default	Ranges	Step
Comm. Mode	Speed	9600	2400/4800/9600/19200bps	
For selecting the communication Baud rate				

4-5-5-2-2 D/L Confirm menu

Description	Classification	Default	Ranges	Step
D/L Confirm	Confirm	Sometime	Yes/No/Sometime	
For selecting and modifying Data Link Confirm				

4-5-5-2-3 D/L menu

Description	Classification	Default	Ranges	Step
D/L Setting	Retries	0	0~2	1
	Timeout	30	0s~100s	1s
For selecting and modifying Data Link Layer				

4-5-5-2-4 A/L Confirm menu

Description	Classification	Default	Ranges	Step
A/L Confirm	Confirm	Enable	Enable/Disable	

4-5-5-2-5 A/L menu

Description	Classification	Default	Ranges	Step
A/L Setting	Retries	0	0~2	1
	Timeout	40	0s~100s	1s

4-5-5-2-6 Unsolicited Mode menu

Description	Classification	Default	Ranges	Step
Unsolicited Mode	Unsol. MSG	Enable	Enable/Disable	
	Unsol. Tirne	5	10ms-5000ms	10ms

4-5-5-2-7 Unsolicited Class menu

Description	Classification	Default	Ranges	Step
Unsolicited Class	Class 0	Disable	Enable/Disable	
	Class 1	Disable	Enable/Disable	
	Class 2	Disable	Enable/Disable	
	Class 3	Disable	Enable/Disable	

4-5-5-2-8 Master Address menu

Description	Classification	Default	Ranges	Step
Master Address	Address	65534	1~ 65534	1

4-5-5-2-9 DNP Address menu

Description	Classification	Default	Ranges	Step
DNP Address	Address	65534	1~ 65534	1

4-5-5-2-10 SBO Time menu

Description	Classification	Default	Ranges	Step
SBO Time	Time	15	1s-255s	1

4-5-5-2-11 Debounce Time menu

Description	Classification	Default	Ranges	Step
Debounce Time	Debounce	20ms	10ms~100ms	5ms

4-5-5-2-12 Multiframe Interval menu

Description	Classification	Default	Ranges	Step
Multiframe Interval	Interval	100ms	100ms~5000ms	10ms

4-5-5-3 System

4-5-5-3-1 Delay Time AC Supply menu

Description	Classification	Default	Ranges	Step
Delay Time	AC Supply	100ms	100ms~60000ms	100ms

4-5-5-3-2 Change Password menu

Description	Classification	Default	Ranges	Step
Change Password		1111	0000~9999	1

4-5-5-3-3 Ethernet Config menu

Description	Classification	Default	Ranges	Step
Ethernet Config	Ip Address	192.168.1.9		1
	Subnet Mask	255.255.255.0		1
	Default Getway	192.168.1.1		1
	DNS Server	0.0.0.0		1
	Port Number	8080		1

4-5-5-3-4 PT Turn menu

Description	Classification	Default	Ranges	Step
PT Turn		100	100~400	1

4-5-5-3-5 CT Turn menu

Description	Classification	Default	Ranges	Step
CT Turn		1000	100~1000	1

4-5-6 Device Management

Time Adjust		Adjust Time and date
Update Firmware		Allow upgrade after USB connected
Clear Data		Clear the data
Restore Factory	Restore Config	Restore DNP3 config to default
	Restore Setting	Restore setting config to default

System Info	Device information (serial number, last calibration date and time, last version)
-------------	--

4-5-7 Calibration

Voltage, current and phase could be calibrated in this menu.

CALIBRATION

Voltage Gain

Current Gain

Phase Sync

Source Voltage(KV)

VA: ◀ 0.0 ▶

VB: ◀ 0.0 ▶

VC: ◀ 0.0 ▶

Load Voltage(KV)

VR: ◀ 0.0 ▶

VS: ◀ 0.0 ▶

VT: ◀ 0.0 ▶

Save

Exit

Current(A)		
IA:	◀ 0 ▶	
IB:	◀ 0 ▶	
IC:	◀ 0 ▶	
IN:	◀ 0 ▶	


Save Exit

Different Phase	
Diff Phase 1-1	265
Diff Phase 2-2	22
Diff Phase 3-3	9

Save Exit


4-5-8 Battery Status

Battery and charger status could be viewed in this menu.



4-5-9 Fault Ind. Reset

The faults could be restarted from this menu.



4-5-10 Lamp Test

The status of the LED and LCD could be checked in this menu.

Lamp Test

Do lamp test?

5- DNP 3.0 profile for remote communication

DNP 3.0 DEVICE PROFILE DOCUMENT	
Requires Application Layer Confirmation <input type="checkbox"/> Never <input checked="" type="checkbox"/> Always <input type="checkbox"/> When Reporting Event Data(Slave Devices Only) <input type="checkbox"/> When Sending Multi-Fragment Responses(Slave Devices Only) <input type="checkbox"/> Sometimes <input type="checkbox"/> Configurable As:	
Timeouts While Waiting For: Data Link Confirm: Complete Appl. Fragment: Application Confirm: Complete Appl. Response: Others:	<input type="checkbox"/> None <input type="checkbox"/> Fixed At ___ <input type="checkbox"/> Variable <input checked="" type="checkbox"/> Configurable <input checked="" type="checkbox"/> None <input type="checkbox"/> Fixed At ___ <input type="checkbox"/> Variable <input type="checkbox"/> Configurable <input type="checkbox"/> None <input type="checkbox"/> Fixed At ___ <input type="checkbox"/> Variable <input checked="" type="checkbox"/> Configurable <input checked="" type="checkbox"/> None <input type="checkbox"/> Fixed At ___ <input type="checkbox"/> Variable <input type="checkbox"/> Configurable
Sends Executes Control Operations: WRITE Binary Outputs <input type="checkbox"/> Never <input checked="" type="checkbox"/> Always <input type="checkbox"/> Sometime <input type="checkbox"/> Configurable SELECT/OPERATE <input type="checkbox"/> Never <input checked="" type="checkbox"/> Always <input type="checkbox"/> Sometime <input type="checkbox"/> Configurable DIRECT OPERATE <input type="checkbox"/> Never <input checked="" type="checkbox"/> Always <input type="checkbox"/> Sometime <input type="checkbox"/> Configurable DIRECT OPERATE _NO ACK <input type="checkbox"/> Never <input checked="" type="checkbox"/> Always <input type="checkbox"/> Sometime <input type="checkbox"/> Configurable Coont > 1 <input checked="" type="checkbox"/> Never <input type="checkbox"/> Always <input type="checkbox"/> Sometime <input type="checkbox"/> Configurable Pulse On <input type="checkbox"/> Never <input checked="" type="checkbox"/> Always <input type="checkbox"/> Sometime <input type="checkbox"/> Configurable Pulse Off <input checked="" type="checkbox"/> Never <input type="checkbox"/> Always <input type="checkbox"/> Sometime <input type="checkbox"/> Configurable Latch On <input checked="" type="checkbox"/> Never <input type="checkbox"/> Always <input type="checkbox"/> Sometime <input type="checkbox"/> Configurable Latch Off <input checked="" type="checkbox"/> Never <input type="checkbox"/> Always <input type="checkbox"/> Sometime <input type="checkbox"/> Configurable Queue <input checked="" type="checkbox"/> Never <input type="checkbox"/> Always <input type="checkbox"/> Sometime <input type="checkbox"/> Configurable Clear Queue <input checked="" type="checkbox"/> Never <input type="checkbox"/> Always <input type="checkbox"/> Sometime <input type="checkbox"/> Configurable Attach Explanation If 'Sometimes' Or 'Configurable' Was Checked For Any Operation.	
Reports Binary Input Change Events When No Specific Variation Requested: <input type="checkbox"/> Never <input checked="" type="checkbox"/> Only Time-Tagged <input type="checkbox"/> Only Non-Time-Tagged <input type="checkbox"/> Configurable	Reports Time-Tagged Binary Input Change Events When No Specific Variation Requested: <input type="checkbox"/> Never <input checked="" type="checkbox"/> Binary Input Change With Time <input type="checkbox"/> Binary Input Change With Relative Time <input type="checkbox"/> Configurable(Attach Explanation)

DNP 3.0 DEVICE PROALE DOCUMENT	
Sends Unsolicited Responses: <input type="checkbox"/> Never <input type="checkbox"/> Configurable <input checked="" type="checkbox"/> Only Certain Objects <input type="checkbox"/> Sometimes(Attach Explanation) <input checked="" type="checkbox"/> ENABLE/DISABLE UNSOLICITED Function Codes Supported	Sends Static Data In Unsolicited Responses: <input type="checkbox"/> Never <input checked="" type="checkbox"/> When Device Restarts <input checked="" type="checkbox"/> When Status Flags Change No Other Options Are Permitted
Default Counter Object/Variation: <input type="checkbox"/> No Counters Reported <input type="checkbox"/> Configurable(Attach Explanation) <input checked="" type="checkbox"/> Default Object :20 Default Variation :6 <input checked="" type="checkbox"/> Point-By-Point List Attached	Counters Roll Over At: <input type="checkbox"/> No Counters Reported <input type="checkbox"/> Configurable(Attach Explanation) <input checked="" type="checkbox"/> 16 Bits <input type="checkbox"/> 32 Bits <input type="checkbox"/> Other Value: _____ <input type="checkbox"/> Point-By-Point List Attached
Sends Multi-Fragment Responses: <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	

6- DNP3 stages:

6-1 Binary input point

Binary Input Point			
Static (Steady-State) Object Number : 1			
Change Event Object Number : 2			
Request Function Codes Supponed : L(Read)			
Static Variation Reported When Variation 0 Requested : 1			
Change Event Variation Reported When Variation 0 Requested : 2			
Point Index	Name/Description	Default Change Event Assigned Class (1,2,3, Or None)	Object / Variation
0	Closer/Open	1	01/01,01/02,02/02
1	Local/Remote	2	01/01,01/02,02/01
2	Lock/Unlock	2	01/01,01/02,02/01
3	Gas Pressure Low	2	01/01,01/02,02/01
4	Banery Status	2	01/01,01/02,02/01
5	Battery/ Charger Fail	1	01/01,01/02,02/02
6	FI Permanent(A)	1	01/01,01/02,02/02
7	FI Permanent(B)	1	01/01,01/02,02/02
8	FI Permanent(C)	1	01/01,01/02,02/02
9	FI Permanent(N)	1	01/01,01/02,02/02
10	FI Temporary(A)	1	01/01,01/02,02/02
11	FI T Emporary(B)	1	01/01,01/02,02/02
12	FI T Emporary(C)	1	01/01,01/02,02/02
13	FI T Emporary(N)	1	01/01,01/02,02/02
14	Source Lose Voltage (Vab)	1	01/01,01/02,02/02
15	Source Lose Voltage (Vbc)	1	01/01,01/02,02/02
16	Source Lose Voltage (Vca)	1	01/01,01/02,02/02
17	Load Lose Voltage (Vrs)	1	01/01,01/02,02/02
18	Load Lose Voltage (Vst)	1	01/01,01/02,02/02
19	Load Lose Voltage (Vtr)	1	01/01,01/02,02/02
20	Mechanisrn Lock	2	01/01,01/02,02/01
21	Door Open	1	01/01,01/02,02/02
22	Ext. AC Power Loss	2	01/01,01/02,02/01
23	Different Phase A-R	2	01/01,01/02,02/01
24	Different Phase B-S	2	01/01,01/02,02/01
25	Different Phase C-T	2	01/01,01/02,02/01
26	Banery Discharged	1	01/01,01/02,02/02
27	Unsolicited Class 1		01/01,01/02
28	Unsolicited Class 2		01/01,01/02
29	Unsolicited Class 3		01/01,01/02
30	Diagoostic Fail	1	01/01,01/02,02/02
31	Preparation1		01/01,01/02

6-2 Binary output point

Binary Output Point Control Relay Output Blocks Object Number : 12 Request Function Codes Supported : 3(Read), 4(Operate), 5(Directoperate), 6(Directoperate, Noack)				
Point Index	Name/Description		Default Change Event Assigned Class (1,2,3, Or None)	Object Variation
0	Close	Pulse ON		12/01
	Open	Pulse ON		
1	Lock	Pulse ON		12/01
	Unlock	Pulse ON		
2	Battery Test	Pulse ON		12/01
3	FI Reset	Pulse ON		12/01
4	Spare	Pulse ON		12/01
		Pulse ON		

6-3 Counters

Binary Counters Static (Steady-State)Object Number : 20 Change Event Object Number: 22 Request Function Codes Supported : 1(Read) Static Variation reported When Variation 0 Requested : 6 Change Event Variation Reported When Variation 0 Requested : 8			
Point Index	Name/Description	Default Change Event Assigned Class (1,2,3, Or None)	Object /Variation
0	Restart Count		20/02,20/06
1	Switch Count		20/02,20/06
2	Permanent FI Count	2	20/02,20/06
3	Temporary FI Count	2	20/02,20/06

6-4 Analog input

Analog Inputs			
Static (Steady-State) Object Number : 30			
Change Event Object Number : 32			
Request Function Codes Supported : 1(Read)			
Static Variation Reported When Variation 0 Requested : 2			
Change Event Variation Reported When Variation 0 Requested : 4			
Point Index	Name/Description	Default Change Event Assigned Class (1,2,3, Or None)	Object /Variation
0	Current (A)		30/2,30/4
1	Current (B)		30/2,30/4
2	Current (C)		30/2,30/4
3	Current (N)		30/2,30/4
4	Pick Current (A)	3	30/2,30/4,32/4
5	Pick Current (B)	3	30/2,30/4,32/4
6	Pick Current (C)	3	30/2,30/4,32/4
7	Pick Current (N)	3	30/2,30/4,32/4
8	Average Current (A)	2	30/2,30/4,32/2
9	Average Current (B)	2	30/2,30/4,32/2
10	Average Current (C)	2	30/2,30/4,32/2
11	Average Current (N)	2	30/2,30/4,32/2
12	Source Voltage (Va)		30/2, 30/4
13	Source Voltage (Vb)		30/2, 30/4
14	Source Voltage (Vc)		30/2, 30/4
15	Current (A)	3	30/2,30/4,32/4
16	Current (B)	3	30/2,30/4,32/4
17	Current (C)	3	30/2,30/4,32/4
18	Current (N)	3	30/2,30/4,32/4
19	Load Voltage (Vr)		30/2, 30/4
20	Load Voltage (Vs)		30/2, 30/4
21	Load Voltage (Vt)		30/2, 30/4
22	Power Factor(A)		30/2, 30/4
23	Power Factor(B)		30/2, 30/4
24	Power Factor(C)		30/2, 30/4
25	Apparent Power (A)		30/2, 30/4
26	Apparent Power (B)		30/2, 30/4
27	Apparent Power (C)		30/2, 30/4
28	Active Power (A)		30/2, 30/4
29	Active Power (B)		30/2, 30/4
30	Active Power (C)		30/2, 30/4

31	Reactive Power (A)		30/2, 30/4
32	Reactive Power (B)		30/2, 30/4
33	Reactive Power (C)		30/2, 30/4
34	Temperature		30/2, 30/4
35	Version		30/2, 30/4

7- Earthing

The control panel is connected to earth by a standard copper cable using the earth terminal at the bottom of the enclosure which is compatible with required standards. Please make sure that the earthing system is connected correctly due to local designing.

8- Control cable and power cable

The control cable is manufactured with sockets at both sides and has a length of 8 meters. In order to prevent shocks due to wind and external pressures which could damage the cable, it should be completely fastened.

The male socket of the control cable (37 pins) should be connected to the switch and the female socket should be connected to the control panel. The female socket of the power cable (3 pins) should be connected to the control panel and the other end of it to the external power supply (voltage transformer or low voltage network). Make sure that all connections are connected correctly.